




Molten Salt Reactor
P R O G R A M

Examination of $\text{PuCl}_3\text{-AmCl}_3\text{-NaCl}$ Salt

Delia Perez-Nunez, Robin Roper, Michael Woods, Mikael Karlsson, Scott Middlemas, Nick Erfurth, Zach Heim, Carson McNair, Justyn Gillish, Ryan Johnson, David Chichester, Scott Thompson, James Johnson, Jay Hix, and Toni Karlsson

Idaho National Laboratory

Outline & Milestones

- Outline
 - Background
 - Experimental Setup
 - Results
 - Conclusion
- Work Package Milestones
 - **M2AT-26IN0704025:** Complete Synthesis of Plutonium/Americium (Pu/Am) Metal to Chloride and Initiate Characterization of the Salt – **on schedule**
 - **M3AT-26IN0704026:** Complete Initial Thermal Property Measurements of $\text{PuCl}_3\text{-AmCl}_3\text{-NaCl}$ Salt – **on schedule**




Background

- Many advantages of MSR's

- Safety
- **Fuel Flexibility & Efficiency**
 - Can accommodate Th/U, U, Pu cycles, waste burner, high fuel utilization, online refueling and chemistry control
 - Can be efficient at "burning up" fuel, leaving behind far less long-lived radioactive waste
- Waste Reduction
- Economics & Practicality
- Proliferation Resistance
- Still many challenges!

- Waste Burner MSR's

- Utilize U/TRU as fuel
- Burn (i.e. transmutate) long lived fission products into shorter-lived fission products
- Good for waste and disposal
- Enables a closed fuel cycle



Hazards

- We have never performed a hydride run on Am containing material before!
 - Graded approach
 - 5g batch to start
 - Then 95g batch

Warning Energetic Reaction

- Use thermodynamic data to predict energy, compare U and Pu
- Follow previous procedure for UCl_3 and PuCl_3 synthesis
- Add NaCl carrier salt will absorb energy (heat) during synthesis
- Mix Pu-Am metal in slowly with NaCl + NH_4Cl
- Slow heating rate (10°C/hr) to limit energy introduced into chlorination reaction

Warning Gas from Synthesis




- Drager tubes in glovebox (detect NH_3)
- Steel wool on top of glassy crucible as indicator for HCl gas
- Run experiment with 1% excess NH_4Cl
- Quantities of off gases $\text{NH}_3 = 26.7\text{g/batch}$ ($\sim 21,000$ ppm if all HN_3 was in GB at one time), $\text{H}_2 = 1.567\text{g/batch}$
- Bypass glovebox purification beds during synthesis

Warning Radiological

- High dose material
- Use graded approach for unknown processes
- Am and Pu powders are known to be “flighty”
- Reduce number of pours

Synthesis


- Starting Material
 - Pu-Am alloy containing 80Pu-18Am-2U
 - Dried NaCl and NH₄Cl
- Perform hydride/de-hydride, <50 mesh
- Convert metal to chloride salt
- Salt composition (target)
 - 40PuCl₃-9AmCl₃-50NaCl (mol %)
- Verify elemental and isotopic composition of starting metal and salt
- Characterize salt to determine melting point, density, and heat capacity



Hydride

Dehydride

Chlorination



Pu-Am metal alloy that will be reduced in size and converted to a chloride salt (top, right). Gibb's free energy predictions for hydriding actinides (top, left). Chemical reactions for synthesis (bottom, left). Hydride/de-hydride run process (bottom, right).


Synthesis in pictures



Pu-Am metal material, ~350g (left), ~100g Pu-Am metal starting material (middle), Pu-Am powder after hydride/de-hydride (right)



NaCl and NH_4Cl in mixing container with fractions of Pu-Am metal being added (left) and NaCl, NH_4Cl , and Pu-Am metal mixed



Fuel Manufacturing Facility (FMF) operator assembling furnace for fuel salt synthesis




$40\text{PuCl}_3\text{-}9\text{AmCl}_3\text{-}50\text{NaCl}$ (target) fuel salt puck (left) and broken up puck (right)



0.250g $\text{PuCl}_3\text{-AmCl}_3\text{-NaCl}$ powder sample for analytical laboratory

Chemical Analysis

- *Data is preliminary*
- Pu/Am Starting Material
 - 80Pu-18Am-2U (assumed)
 - 80.2Pu-18.8Am-0.8Np-0.2U (preliminary)
- Salt
 - 40PuCl₃-9AmCl₃-50NaCl (target)
 - 36.3PuCl₃-8.8AmCl₃-0.6NpCl₃-0.2UCl₃-53NaCl (preliminary)
- Thoughts
 - Presence of Np was indicated from gamma spec
 - Am-241 data from gamma spec aligns well with M/Z-241 from ICP-MS data



ICP-MS Data - Preliminary




Isotope	Metal		Salt		Isotope	Metal		Salt	
	µg/g	% Error	µg/g	% Error		µg/g	% Error	µg/g	% Error
Cr	40.5	±20%	76.9	±20%	Sm-147	<0.2	N/A	<0.2	N/A
Ga	<5	N/A	<5	N/A	Sm-149	<0.3	N/A	<0.3	N/A
Ge	<9	N/A	<10	N/A	Sm-152	<0.2	N/A	0.165	±35%
Ni	53.8	±25%	64.7	±10%	Eu-153	<0.2	N/A	<0.2	N/A
Co-59	<20	N/A	13.2	±10%	Gd-155	<0.3	N/A	<0.3	N/A
Sr-86	<30	N/A	18.9	±10%	M/Z-134	<6	N/A	<5	N/A
Sr-88	<300	N/A	169	±5%	M/Z-148	0.333	±30%	0.35	±30%
Zr-91	<3	N/A	<3	N/A	M/Z-150	0.308	±15%	0.319	±30%
Zr-94	5.7	±30%	7.12	±20%	M/Z-151	<0.2	N/A	<0.2	N/A
Nb-93	<2	N/A	<2	N/A	M/Z-154	<0.4	N/A	<0.4	N/A
M/Z-90	<20	N/A	9.53	±10%	Hf-178	<0.5	N/A	<0.5	N/A
M/Z-92	6.74	±20%	8.89	±20%	Hf-180	<1	N/A	<1	N/A
M/Z-96	5.71	±15%	8.09	±20%	Pt-194	<2	N/A	<2	N/A
Mo-95	4.33	±20%	6.38	±15%	Pt-195	<2	N/A	<2	N/A
Mo-97	2.73	±20%	4.11	±15%	Pb-206	45.6	±20%	38.9	±10%
Mo-98	6.78	±10%	9.75	±20%	Pb-207	43	±20%	36.2	±10%
Mo-100	2.8	±15%	3.98	±15%	Pb-208	101	±20%	84.1	±10%
Cs-133	<2	N/A	1.23	±30%	Th-232	5.05	±15%	10.3	±10%
Cs-135	<20	N/A	12.4	±10%	U-233	<0.2	N/A	0.164	±35%
Ba-136	<20	N/A	14.7	±10%	U-234	134	±5%	295	±5%
Ba-138	131	±38%	139	±10%	U-235	808	±5%	1780	±5%
Ce-140	<8	N/A	6.86	±15%	Np-237	8140	±10%	7640	±5%
Ce-142	2.23	±20%	2.56	±15%	Pu-239	647000	±5%	379000	±5%
M/Z-134	<6	N/A	<5	N/A	Pu-240	129000	±5%	74800	±5%
M/Z-137	<30	N/A	21.6	±15%	M/Z-236	581	±5%	1290	±5%
La-139	3.91	±35%	3.78	±15%	M/Z-238	490	±5%	543	±5%
Pr-141	0.905	±25%	0.86	±15%	M/Z-241	182000	±5%	111000	±5%
Nd-143	<0.8	N/A	0.652	±30%	M/Z-242	2830	±15%	1630	±10%
Nd-144	1.21	±20%	1.38	±25%	M/Z-243	<0.07	N/A	<0.08	N/A
Nd-145	0.419	±25%	<0.5	N/A					
Nd-146	0.867	±30%	0.909	±20%					

>15ppm = bold



Phase Behavior


- Solidus: 438.8°C
- Liquidus: 562.9°C
- Indications from the thermogram
 - Binary eutectic system or close to?
 - Presence of AmCl_3 lowers solidus compared to NaCl-PuCl_3 , 439 vs 450°C
 - Expected from models (Juliano Schorne-Pinto)
 - Can get a rough estimation of composition from NaCl-PuCl_3 phase diagram
 - Purposely did not aim for eutectic, can “dilute” salt for later studies




Density

- Archimedes' hydrostatic method
 - Calibrated 1cc bobber with 0.1mm wire
 - Each calibrated on a calibrated balance
 - Air, water, ethanol
 - 5 mass measurements per temp
 - Heating, cooling, random cycles
- Density
 - Validated between 550 to 800°C

Densitometer setup in FMF




Equipment	Description
Furnace	Ventura electromelt with graphite crucible
Bobber	Ta, ESPI Metals 99.99%, $1.0408 \pm 0.0006 \text{ cm}^3$
Wire	0.1 mm W, Alfa Aesar, 99.95% metals basis, Batch #10404 Lot #X28G043
Crucible	GAZA2, 25 mL Sigradur cylindrical crucible, HTW Germany
Balance, Bottom-loading	Mettler Toledo WXSS204, INL ID#525063 tolerance 0.8 mg
Thermocouple	Omega TJ36-CAIN-116U-8-SMPW-M, Inconel sheathed K-type ungrounded
Thermocouple Reader	Omega HH502, s/n 21000159, uncertainty 0.05% of reading + 0.3 K



Heat Capacity

- Performed on DSC in glassy carbon crucibles at 5°C/min
- Difficult measurement for us this time around
 - New staff
 - Instrument availability
- One measurement inline with expectations...
 - But it was not reproducible after first heating

Karlsson, T.Y., et al., *Synthesis and thermophysical property determination of NaCl-PuCl₃ salts*. Journal of Molecular Liquids, 2023. **387**: p. 122636.



Dose Rate & Counting

- Passive Prompt Gamma-Ray Alpha Activation Analysis (PGAAA) for MSR Fresh Fuel Safeguards Verification
 - David Chichester Safeguards lead PI
 - Office of Defense Nuclear Nonproliferation Research and Development Project
- Assess the utility of PGAAA signatures as a complementary approach to traditional nondestructive assay (NDA) measurements for inferring U/Pu enrichment/isotopic content and mass within fresh molten salt reactor (MSR) fuel
- PGAAA emissions clearly seen in Am/Pu-bearing NaCl salt
- Relative intensity of observed Pu and Am gamma rays changed during melting
 - Indication of dynamic nonhomogeneity
 - Dynamic nonhomogeneity during melting suggests that Am/Pu are moving during the phase transition
 - Dynamic nonhomogeneity was different if the salt started as a powder vs. a solid monolith; evidence of change also seen as change in observed external dose rate



94.552g, 1.6 R/hr (on contact)

94.734g, 3.2 R/hr



94.828g, 4.5 R/hr



30.881g, 1.2 R/hr

0.250g, 100 mR/hr

168.563g, 2.6 R/hr




This work is partially supported by the U.S. Department of Energy, National Nuclear Security Administration, Office of Proliferation Detection's Safeguards Portfolio."

Conclusion

- Successfully synthesized a $\text{PuCl}_3\text{-AmCl}_3\text{-NaCl}$ salt
- Salt could be diluted with carrier to further assess phase diagram and determine eutectic composition
- Preliminary elemental and isotopic data is available, will finish analysis in coming weeks
- Performed phase behavior, density, and heat capacity studies
 - Heat capacity needs further work
- Dose rate of material presented challenges and scientific opportunities
- Acknowledgements – FMF, ARL, the entire INL team, MSR Campaign, Juliano, US-DOE NNSA (Office of Proliferation Detection's Safeguards Portfolio)



Your email address



Molten Salt Reactor
P R O G R A M